

# Frontier™

Frontier is a trademark of Matrix Systems, Inc.

## **Elevator Control – Frontier Optional Feature**

### OVERVIEW

Frontier's Elevator Control optional feature controls badgeholder access to elevator floors as well as allows for operator control of elevator readers and elevator floors. The Elevator Control feature offers:

Access to elevator readers and elevator floors is specified by grouping one or more elevator readers together in an elevator bank. Frontier's Elevator Control feature is flexible allowing any number of elevator readers to be assigned to an elevator bank with each elevator bank supporting up to 64 floors.

To minimize the amount of administrative overhead required for setup and maintenance, Frontier's intuitively designed Graphical User Interface (GUI) allows Frontier users to easily configure elevator access privileges by creating multiple descriptive badgeholder access groups. The system supports the creation of access groups by selecting one or more elevator floors. Assignment of each elevator floor to an access group is qualified by a user-defined schedule and optionally qualified by an activation date, expiration date and/or permission for offline access. The access groups are then assigned to the badgeholder(s).

Control of elevator readers and elevator floors is convenient using Frontier. Elevator floors and/or elevator readers may be assigned an unlock schedule. In addition, elevator readers and elevator floors may be manually controlled just as doors may be manually controlled – with one command, all elevator readers can be secured.

The Elevator Control feature uses the proven and reliable RCM2 (Matrix Reader Control Module), which is of uncompromising quality and reliability.

### REQUIREMENTS

#### **Frontier**

- Version 3.0 or greater
- Elevator Control License

#### **Matrix Hardware Requirements**

- RCM2s

*Matrix Systems maintains a policy of continuous product improvement. Specifications are subject to change at any time.*